

KP&P PSS USER MANUAL

19 DEC. 2011



CONTENTS



1.	I. KP&P PSS LINE-UP		
	E-BODY PROTECTOR	R (EBP) -	4
	SCORING BOX		5
	RECEVER		7
2.	OPERATION SOFTWARE		
	RULE SETTING		8
	RULE SETTING DISPI	LAY	9
	registration disp	LAY	9
	CONTROL PANEL		10
	OPERATIING COMPL	JTER'S DISPLAY	11
	EBP TEST MODE		12



EBP





Referee Scoring Box



KP&P PSS Wireless System

Receiver

Foot Protector



Operation Program




EBP

How to power on/off and Register



- 1 Power ON / OFF
 - Press power button over 3 sec until hear Bleep sound
 - 'Power LED (red)' ON / OFF
- ② Registration
 - Press 'Registration' button after press 'vest reg' icon in operation program
 - "Registered' message will be shown on program display and green light will be on with beep sound when registered.



How to Recharge





- ① Be ware of discharge of electricity (recharge it before 25% left)
- 2 2 hours for full-charge (Run EBP for 10 hours normally)
- 3 Green light is on while recharging and off after competing recharging



SCORING BOX

How to power on/off and Register

1 Power ON / OFF

- Press power button over 3 sec until hear Bleep sound
- 'Power LED' ON / OFF

② Registration

- Press 'Registration' button after pressing 'ref 1, ref 2,...' icon in operation program
- "Registered' message will be shown on program display and green light will be on with beep sound when registered.



How to Recharge





- ① Be ware of discharge of electricity (recharge it before 25% left)
- 2 2 hours for full-charge (Run EBP for 10 hours normally)
- 3 Green light is on while recharging and off after competing recharging



SCORING BOX

How to Work




- ① Fist point (1 point)
 - Referee pressed 'fist' button when the attack is a fist punch.
 - Valid point is expressed when at least two of three referees pressed button.
- ② Technical Point (1 point)
 - Referee pressed 'technical' button when the attack is a technical kick.
 - Valid point is expressed when at least two of three referees pressed button.
- ③ Head Point (3 points)
 - Valid point is expressed when at least two of three referees pressed button.



RECEIVER

How to connect to computer




- ① 'Power LED' is on while receiver is connected to the powered computer
- ② 'Activation LED' is on while operation software is activated.

2. OPERATION SOFTWARE




Main Display



Procedure

- 1. Rule Setting
- 2. Registration
- 3. Control Panel
- 4. Result View

Rule Setting





- Choose Court No.
 - -Make sure each Court has own No.
- ② Set Competition Class (Set Hit power level)
 - See the next page for more information.
- ③ Select 'Electronic Foot Protectors'
- 4 Setting Judges No.
- ⑤ Toggle to 'Use WTF Rule'
- ⑥ Toggle to 'Use Vibration' mode in Referee Box
 - It does not apply to WTF rule.
- 7 Time Setting

2. OPERATION SOFTWARE



Rule Setting Display






* Valid Power Level Setting

- 1) Check Class in Competition Class
- 2 Amending EBP Valid Power level
- ③ Press 적용(Apply) Button
- (4) 'Electronic Head Gear' is not available now

Registration Display




- Extending Registration Window by Clicking Correction
- Registration players in advance
 - Type Match No, Gender,
 Weight, Name and Nation
 Click 'Registration'
 - OK to Register multi Players
 - * OK to add players without typing name
- ③ List of Resisted Players Double click the resisted player list (red square #3)

- 4 Registration of EBP
 - Double click the resisted player list (red square #3)
 - List Information is shown on Equipment Registration
 - Click Blue 'Vest Reg.' and press the registration button on blue EBP before time bar ends
 - When registered, 'registered' message is seen with green high light
 - Follow same procedure on Red
 - Click CLOSE




Control Panel






Operating Computer's Display




2. OPERATION SOFTWARE





EBP Test Mode





- 1) Press 'TEST' on the right side of Match Display
- 2) Pop-up window, 'Are you sure to go to Equipment Test Mode?' Click 'Yes'
- 3 It turns 'TEST' mode & Ready to TEST
- 4 Exit to Previous Display Press 'RETURN' (on the right side Test)
- ⑤ Pop-up Window, 'Are you sure to exit from Equipment Test Mode? Click 'Yes'





Information